

Typical Gas310/610 boiler field wiring - Remote 0-10v controlled Operation

- BMS control via 0-10v, connect 0-10v signal on X29.11 & X29.12, boiler modulates based on temperature or output according to signal sent to boiler.
- Operating Status (dry contact normally open relay)
- LWCO & External Hi-Limit fault attenuation on control, connect devices in series on X29.1 & X29.2 – Generates fault code flashing numbers **X** **X|X** requires manual reset of safety devices first then reset of the boiler control. **X** = Code display & **X|X** = **!** display
- Optional flow switch application (Start interlock only)
- Optional LWCO & Safety Hi limit – can be wired on X29.5 & X29.6 if power failures are common, note boiler display will not display fault code, but a shut-off code **b** **X|X** (Flashing dots)

NOTE:

- A) Fault codes in both (Alternating flashing codes **X** = Code display & **X|X** = **!** display) require manual reset of the device if equipped and then boiler control.
- B) Shutoff codes **b** **X|X** (Flashing dots) do not require manual intervention, when condition returns to normal, the boiler automatic resume normal operation.


Note: Gas610 models wiring applies to each module

LEGEND:

- ① Main fuse disconnect
- ② Service switch
- ③ External Hi Limit
- ④ External LWCO device
- ⑤ External Flow Switch (optional not required)

L Line 120v **⊕** Earth ground
N Neutral

L (NC) Output 120v (normally closed)
L (NO) Output 120v (normally open)
C Common dry contact
N_o Normally open dry contact
N_c Normally closed dry contact



Typical Gas310/610 boiler field wiring – Local (Internal) Modulation Operation


- On/Off control or jumper – modulates according to internal set-point (Connect X29.9 & X29.10)
- Operating Status (dry contact normally open relay)
- LWCO & External Hi-Limit fault attenuation on control, connect devices in series on X29.1 & X29.2 – Generates fault code flashing numbers **X** **12** requires manual reset of safety devices first then reset of the boiler control. **X** = Code display & **12** = display
- Optional flow switch application (Start interlock only)
- Optional LWCO & Safety Hi limit – can be wired on X29.5 & X29.6 if power failures are common, note boiler display will not display fault code, but a shut-off code **b** **X****X** (Flashing dots)

NOTE:

- A) Fault codes in both (Alternating flashing codes **X** = Code display & **X****X** = display) require manual reset of the device if equipped and then boiler control.
- B) Shutoff codes **b** **X****X** (Flashing dots) do not require manual intervention, when condition returns to normal, the boiler automatic resume normal operation.

Note: Gas610 models wiring applies to each module

LEGEND:	
①	Main fuse disconnect
②	Service switch
③	External Hi Limit
④	External LWCO device
⑤	External Flow Switch (optional not required)
L	Line 120v
	Earth ground
N	Neutral
L (NC)	Output 120v (normally closed)
L (NO)	Output 120v (normally open)
C	Common dry contact
N_o	Normally open dry contact
N_c	Normally closed dry contact



Typical Gas310/610 boiler field wiring – 2 stage (L-H-L) Operation

- On/Off control or jumper – for 1st stage modulates 20-50% of boiler output according to internal set-point (Contacts X29.9 & X29.10)
- 2nd stage controller or jumper modulates 50-100% of boiler output according to internal set-point Contacts X29.7 & X29.8)
- Operating Status (dry contact normally open relay)
- LWCO & External Hi-Limit fault attenuation on control, connect devices in series on X29.1 & X29.2 – Generates fault code flashing numbers **X** **1****2** requires manual reset of safety devices first then reset of the boiler control. **X** = Code display & **1****2** = **!** display
- Optional flow switch application (Start interlock only)
- Optional LWCO & Safety Hi limit – can be wired on X29.5 & X29.6 if power failures are common, note boiler display will not display fault code, but a shut-off code **b** **X****X** (Flashing dots)

NOTE:

- A) Fault codes in both (Alternating flashing codes **X** = Code display & **X****X** = **!** display) require manual reset of the device if equipped and then boiler control.
 B) Shutoff codes **b** **X****X** (Flashing dots) do not require manual intervention, when condition returns to normal, the boiler automatic resume normal operation.

Note: Gas610 models wiring applies to each module

LEGEND:	
①	Main fuse disconnect
②	Service switch
③	External Hi Limit
④	External LWCO device
⑤	External Flow Switch (optional not required)
⑥	2 nd stage controller
L	Line 120v
N	Neutral
E	Earth ground
L (NC)	Output 120v (normally closed)
L (NO)	Output 120v (normally open)
C	Common dry contact
N_o	Normally open dry contact
N_c	Normally closed dry contact

