



### **Burner end kit installation for DeDietrich ECO310 series**

- 1.-Slide insulation pad **C** into burner end screw.
- 2.-Slide end cap **B** into burner end screw.
- 3.-Attach supplied end nut **A** onto burner end screw and tighten nut.

Note: Supplied replacement end nut may be different from the one shown.