



Baffle Position	Baffle	Fraction	mm	GT 334 A	GT 335 A	GT 336 A	GT 337 A	GT 338 A	GT 339 A
Upper [3rd Pass]	8219-0017	16 1/4	410	0	8	8	4	0	0
Middle [2nd Pass]	8219-0018	22 7/16	570	4	0	0	4	8	8
Lower [1st Pass]	8219-0019	16 1/4	412	2	2	2	2	4	2
	8219-0020	22 1/2	572	0	0	0	0	0	2

How to install

GT334A: install 1 x **8219-0018** in each position A, B, C, and D, total 4 x **8219-0018**. And 1 x **8219-0019** in each position E and F. For a total of 6 Baffles.

GT335A: Install 2 x **8219-0017** in each position A, B, C, and D, total 8 x **8219-0017**. And 1 x **8219-0019** in each position E and F. For a total of 10 Baffles.

GT336A: Install 2 x **8219-0017** in each position A, B, C, and D, total 8 x **8219-0017**. And 1 x **8219-0019** in each position E and F. For a total of 10 Baffles.

GT337A: Install 1 x **8219-0017** and 1 x **8219-0018** in each position A, B, C, and D, total 4 x **8219-0017** and 4 x **8219-0018**. And 1 x **8219-0019** in each position E and F. For a total of 10 Baffles.

GT338A: Install 2 x **8219-0018** in each position A, B, C, and D, total 8 x **8219-0018**. And 2 x **8219-0019** in each position E and F. For a total of 12 Baffles.

GT338A: Install 2 x **8219-0018** in each position A, B, C, and D, total 8 x **8219-0018**. And also 1 x **8219-0019** and 1 x **8219-0020** in each position E and F. For a total of 12 Baffles.